



INSTALLATION DETAILS FOR FENCEGUARDS

Easy to Install:

1. Attach sections end-to-end or overlap.
2. Fasten with 8" ties (provided). Through pre-punched holes spaced every two feet.
3. Install ties so that tails are on outside of fence. Trim tails leaving approximately 1/8" past the locking mechanism. **IMPORTANT: ALLOW FOR EXPANSION & CONTRACTION. FENCE GUARDS SHOULD BE ALLOWED TO MOVE FREELY. Do not over tighten against top of chain link fence. LEAVE AN AIR SAFETY CUSHION ABOVE TOP RAIL**
4. If necessary Fence Guards can be trimmed with a hacksaw and additional holes can be drilled.
5. Remove crowns from posts so entire top of fence is covered and level.

YOUR "ONE-STOP SOURCE" FOR AMERICA'S SPORTS SURFACES & SUPPLIES!

800-247-2326 • www.FENCEGUARDS.com • FAX 908-637-8421
PARTAC PEAT CORPORATION, KELSEY PARK, GREAT MEADOWS, NJ 07838